

Using the Long Reach Hedge Trimmer

- Make sure that you have got a firm footing, and that there is no danger of you slipping or stumbling while 2. working.
- Start the hedge trimmer, then lift it and clip in onto the shoulder strap.
- Make sure that the cutting blades do not accidentally touch anything. If they do, the hedge trimmer may kick back or cause an injury.
- Always keep your left hand on the grip on the shaft, with your right hand on the control handle, 5. controlling the throttle.
- Let the shoulder harness carry the weight of the machine this makes it easier to handle and control.
- Make sure the cutting blade is running at full speed before starting to cut into the hedge.
- Do not try to cut off thick twigs. This hedge trimmer is only for trimming foliage.
- Do not try to cut off all growth in one pass; remove it one layer at a time. Make sure that you can 9
- control the amount you are removing before you take off the final layer.
- Work with a steady swinging action from the bottom upwards when trimming hedge sides
- Beware of debris that may be thrown out by the trimming blade. 11.
- 12. If the hedge trimmer starts to labour and slow down, do not force it so hard. Work at a steady speed o as not to overload the engine.
- If anything jams in the blades while you are working, stop the machine and put it down. Wait until the blades have stopped completely before clearing the obstruction.
- Do not cut close to the ground stones and other debris can be thrown up, and the blades can be 15. Make sure that your work area remains clear - you may need to stop the hedge trimmer to move fallen
- Stop the hedge trimmer before you put it down, or if you need to carry it anywhere. Put the blade
- The gearbox by the cutting blade can get hot after continuous use be careful not to touch it.
- You should always be alert when using the hedge trimmer. If you are tired, leave the job until another 18.
- 19 Stop the engine if leaving the machine unattended.
- 20. Put the blade cover back on when you have finished work.
- If your equipment does not work properly, do not attempt to repair it. Contact the hire company.

Please store this leaflet safely. It may be required for further information







2450 Regents Court

The Crescent









44 (0) 121 333 4109

©Copyright Hire Association Europe April 2011

Any unauthorised reproduction - manually or electronically - is STRICTLY prohibited

2. Move the control lever to the stop position to and stop when the throttle control is released. Check that the nedge thimmer biades fun freely, ONCE THE HEDGE TRIMMER IS RUNNING

check that the hedge trimmer stops properly.

varm up by gentry opening the throttle, be 11. In cold weather, you may need to let the engine control to normal running position

10. It the engine is now running, set the choke cinide the cord back into place so that it recoils

and strongly. Don't pull it too far, or it may

slowly until you can feel that the starter has engaged with the engine, then pull it quickly With your right hand, pull out the starter handle hand on the body of the machine

Hold the hedge trimmer firmly, with your left touching the ground or any obstruction. and make sure that the cutting blades are not plate on the ground. Take off the blade cover attempt is made to start the engine. Place the hedge trimmer squarely on its base

valve, set it. You need to set the decompression valve each time a fresh 2. It your hedge trimmer has a decompression

from the tuel tank. You will not need to do this If your hedge trimmer has a fuel primer bulb,

choke control should be in the normal running Set the choke lever to the choke position if the engine is warm, the Pull the control lever back to the run position.

your hedge trimmer, tollow them. Otherwise, as given you special instructions fo procedure for most nedge trimmers. If the nire

STARTING (FROM COLD)

first attempting to start the engine from cold. e. The choke control should only be used when

- each fresh attempt to start the engine. pedge trimmer - it needs to be pressed by I UIS IS OUIT USED WHEN STARTING THE Your machine may have a decompres when you lifst start the machine from cold.
- This is used to draw fuel from the fuel ta rour macnine may nave a ruei primer bulb. wer forward to the STOP position. to stop the hedge trimmer, push the control
- Under normal running it is at the RUN position The main control lever has two positions. bress the interlock in before you can squeeze
- trigger, to prevent the throttle being squeezed or pressed accidentally. You always need to There is an interlock control on the throttle trimmer to find the controls before you try to
- This is a brief description of the controls found CONTROLS

STARTING THE HEDGE TRIMMER

your fuel can to a safe, cool place

m straight away. I all fuel caps back on properly, and move

- 10. If you spill any fuel on your clothes, change
- It you spill any fuel on the ground, wipe it up or ed cloth carefully 8. Wipe any fuel off the machine. Dispose of fuel
- el on yourself or the machine
- Use a funnel when refueling. Do not spill any prevent dirt falling into the tuel tank.
- Clean the filler cap and the area around it to
- If possible, move the machine away from your













Long Reach Hedge Trimmer

The rules and procedures in force where people are at work may require the person responsible for this equipment to carry out a specific risk assessment.

It is important to read all of this leaflet **BEFORE using the Long Reach Hedge Trimmer**

- Plan your work and think ahead to make sure you will always be working
- This hedge trimmer is a powerful cutting tool which can cause very use it. Do not allow anyone else who is not fully competent to use it. You must take great care at all times when working with the hedge trimmer
- If you are in any doubt about how to use the trimmer, do not use it.
- You must not work near overhead electric cables or supply lines, because there is a serious danger of fatal electric shock. Keep at least 15m (50 feet) away. Petrol is highly flammable. Take care not to cause a fire or explosion
- This hedge trimmer is designed for cutting back and trimming tall hedges and shrubs. Do not try to
- You should wear as a minimum, the following personal protective equipment: helmet EN397; goggles or face shield EN166; ear defenders EN352; SNR=25 minimum; strong gloves; secure boots or shoes with good non-slip soles.
- Hedge trimmers must not be used by minors, or by anyone under the influence of drugs or alcohol.
- Hedge trimmers are designed for use by an able bodied adult. Anyone with either temporary or permanent disability must seek expert advice before using them.

- You must be competent to use this hedge trimmer. Before you start work, check that you fully nderstand all of the following points. If there is anything you do not understand, do not use the he trimmer. Check with your employer, or the hire company
- The hazardous areas on the hedge:trimmer.
- How to stand correctly when using the hedge trimmer and what the correct cutting action is; and How to start, and stop, the hedge trimmer.













Every effort has been made by HAE/EHA to ensure that the information given in this document and supporting materia eading. HAE/EHA cannot accept responsibility for any loss or liability pero of any such document/material. Only Acts of Parliament and Statutory Ins rom the use of any such document/material. Only Acts of Parliament and Statu-have the force of law and only the courts can authoritatively interpret the law.

> 44 (0) 121 333 4109 44 (0) 121 380 4600

The Crescent Birmingham Business Park noo sinegen uch

BAY 788 Iludilos



- 3. Stop the engine and let it cool down.
- stroke oil to 25 measures of petrol (40ml per Otherwise use 1 measure of two special instructions on now much oil to use, atrol. If the hire company have given you Use a fresh mixture of two stroke engine oil

- you must know now to stop it. controls. Before you start the hedge trimme Make sure that you understand all of the comfortably near your right hip.
- so that the hedge trimmer is supported Put the shoulder strap on, and adjust its length company tor this. using a suitable saw - contact the hire
- you need to cut branches, you should consider work other than trimming standing hedges. Do not try to use this hedge trimmer for any the hire company. or use anything found damaged – con
- nand guard that is fitted, and all equipment. Check your hedge trimmer, engine, shaft, any

HEDGE TRIMMERS

- d to wear appropriate personal protective Anybody who is working near to you will also
- wear secure boots or snoes with good non-slip Protect your hands with heavy duty gloves. to prevent it getting caught in the machine. working with this machine. Tie up any long ha You must wear a safety helmet (EN397) when
- SUR=25) giving hearing protection for this



Before Starting Work.

- up to 104 dB(A) wear ear detenders (EN352; 166) when you are working with this machine. You must wear a face shield or goggles (EN
- Paricular Jobs or environments may require a orn whenever you use this hedge trimmer. The following items of personal protective equipment (ppe) are the minimum that should to use the hedge trimme
- who does not have the required competence hedge trimmer. You must not allow anyone All operators must be competent to use the

SHOTARING

- oreign bodies in them. hedges that may have fence wire or othe Do not use the hedge trimmer for trimming need ins equipment.
- against falls. Contact the hire company it you It you need to work from a ladder or a platform, yourself in danger.
- reach the area to be trimmed, without putting Check that you have room to work, and can
- warning signs or barriers around your work Protect other people from the noise and from danger. Warn others to keep away, put up you or could distract you.
- not ripping hazards, and that no-one is near to Make sure that the area is clear and safe, with berror, or gas cylinders.
- danger of explosion. It will ignite fumes from Do not use this hedge trimmer where there is a trimmer indoors or in poorly ventilated locations. breathing toxic fumes, never run the hedge To reduce the risk of serious or fatal injury from ross large gaps
- rimes do not rorget that electricity can jump least 15m (50 feet) away from cables at all danger of coming into contact with the overhead electricity cables. You must keep at Do not use the hedge trimmer where there is a

WORK AREA