







# **Using the Belle Minimix Cement Mixer**

### STARTING THE ENGINE

- Check that the engine and machine controls are set correctly.
- Make sure that you hold the machine firmly so it will not move when you pull the starter.
- Pull the starter handle slowly until you can feel that the starter has engaged with the engine, then pull it quickly and strongly. Don't pull it too far, or it may break
- Guide the cord back into place so that it recoils correctly.

### USING THE BELLE MINIMIX CEMENT MIXER

- Wear your protective equipment including ear defenders, dust mask, goggles and safety
- The engine must be running all the time there is a mix in the drum.
- 3. Do not move the mixer while the drum is full.
- Stop the engine if leaving the machine unattended
- You must clean the mixer and especially the drum as soon as you have finished work, before the mix goes hard.
- If your equipment does not work properly do not attempt to repair it. Contact the hire

Please keep this leaflet safely as it may be required for future reference













www.hae.org.uk

©Copyright Hire Association Europe April 2011

## Any unauthorised reproduction – manually or electronically – is STRICTLY prohibited

move your fuel can to a safe, cool place. 10. Put all fuel caps back on properly, and change them straight away.

9. If you spill any fuel on your clothes, up or cover it with soil.

8. If you spill any fuel on the ground, wipe it tuel soaked cloth carefully.

7. Wipe any fuel off the machine. Dispose of mixer

. brevent petrol seepage when you tilt the 6. Do not fill the tank too full, this will help yourself or the machine. Do not spill any fuel on

Use a funnel and clean petrol when Clean the filler cap and the area around it to prevent dirt falling into the fuel tank.

your work area.

3. If possible move the machine away from 2. Stop the engine and let it cool down.

1. No smoking.

### **BEFUELLING**

drum; the petrol and oil may seep to other parts of the machine. 5. Do not leave the mixer standing on the

heavy or if the ground is rugged, use two sited. If you feel the mixer/stand is too the upright position. Make sure it is firmly the clip. Tilt the stand and mixer back into that it stands on the opening of the drum. Locate the stand into position and lock the elip. Tilt the stend and mixer book into Alternatively one man can tip the mixer so

incking cip. mixer onto the stand and secure with the 3. Two persons can then lift and locate the

ground near to your work area. The stand should be sited on firm level

or without the stand.

to make it easy to empty the drum into a wheelbarrow. The mixer can be used with

stand, which raises the height of the mixer 1. Your Belle minimix is supplied with a

## **QNATS**

take care not to damage the threads. 8. Reverse this procedure to refit the drum, unscrewed, lift the drum off carefully.

transportation, switch off, stand in front of the mixer and turn the drum anticlockwise. When it has fully 7. To remove the drum for storage or nbudur bosinon.

6. Always store the mixer in its normal

removing any stubborn residue of the

rne rotating drum will greatly assist shovels full of clean gravel, with water, in petore the cement mix hardens. the drum and the mixer is washed clean 2. When you have finished work, make sure emptying the mix.

4. Ensure the drum is rotating while or the way.

powerful. It will not stop rotating until the engine is stopped. Keep your hands out 3. The rotation of the drum is slow but very rotating.

other than the mix into the drum while it 2. Do not put your hand, shovel or anything strain the drum shart.

a full load would be difficult and would loading. Do not load a concrete mix into a stationary drum. Starting the mixer with Always start the drum rotating before

### DBUM









When you start the engine the drum will safely near to your work area.

Check that the mixer is sited firmly and company.

not use the mixer - contact the hire stand. If anything is found damaged, do

BETTE MINIMIX CEMENT MIXER

### brotective equipment.

6. Anybody who is working near to you will

full frousers to prevent the mixes coming You should wear gloves, long sleeves and

BS1870/4972). You must wear safety boots (EN345 or

materials that cause dust. FFP3(s) protection) when you are mixing

3. You will need to wear an appropriate machine.

You must wear goggles (EN166 or

may require a higher level of protection. mixer. Particular jobs or environments







# **Belle Minimix Cement Mixer**

The rules and procedures in force where people are at work may require the person responsible for this equipment to carry out a specific risk assessment.

### It is important to read this entire leaflet BEFORE using the Belle Minimix Cement Mixer

- 1. Plan your work and think ahead to make sure you will always be working safely.
- 2. Petrol is highly flammable. Take care not to cause a fire or explosion.
- Cement mixes are harmful to eyes, lungs and skin. Follow any instructions given by the manufacturers of these cement
- 4. This Belle minimix cement mixer is designed for mixing concrete, mortar, plaster and similar compounds with water. IT can also mix composts and other similar materials.
- The action of this mixer can cause injury or damage if the machine is not used in a careful and controlled way.
- 6. If you have not used a Belle mini mix cement mixer before, familiarise yourself with how the machine works before you start on the main task.
- You must have at least the following items of personal protective equipment: goggles: EN166 or BS2092; dust mask - a minimum of EN149 FFP3(s) protection; safety boots to EN345 or BS1870/4972; gloves.
- 8. This machine must not be used by minors, or by anyone under the influence of drugs or
- This Belle mini mix cement mixer is designed for operation by an able bodied adult. Anyone with either temporary or permanent disability must seek expert advice before using it.















effort has been made by HAE/EHA to ensure that the information given in this docum is accurate and not misleading. HAE/EHA cannot accept responsibility for any lot to have arisen from the use of any such document/material. Only Acts of Parliament have the force of law and only the courts can authoritatively interpret the law.

44 (0) 121 380 4600 44 (0) 121 333 4109

**BAY 788 Iludilos** The Crescent Birmingham Business Park noo sinegen uce



suonia de worn whenever you use this equipment (ppe) are the minimum that 1. The following items of personal protective

### **SHOTARING**

barriers around your work area. 4. Protect other people from the noise and dust, warn others to keep away, put

distract you. and that no-one is near to you or could 3. Make sure that the area is clear and safe

ventilation will almost always be required. extraction Mechanical the ventilation required has been fully other indoor situations if its suitability and in domestic premises and only use it in

Using this equipment indoors or in fumes from petrol, or gas cylinders. 1. Do not use this cement mixer where there is a danger of explosion. It will ignite type patrol or assemilaters

carbon monoxide poisoning. Never use it

confined spaces could cause fatal

### **MORK AREA**

веек шедісяі ядлісе: no further contact. If the rash persists Mild dermatitis will heal providing there is

·wəuı uı advice if you get any type of cement mix off your skin immediately. Thoroughly rinse out your eyes and seek medical Thoroughly

3. Wash cement or plastic or plaster mixes was in contact with the skin. rash occurs only where the substance usually itchy and causes flaky skin. The The rash can vary but it is occur when the skin reacts to certa 2. Contact dermatitis is a rash that may

cause contact dermaitis. 1. Wet cement mix is a substance that can

**DERMATITIS CEMENT MIXES AND CONTACT** 

must know how to stop it. before you start the cement mixer, you 4. Make sure you understand the controls

rotate and will not stop rotating until the

7. Check your machine, engine, drum and

also need to wear appropriate personal

into contact with your bare skin.

dustmask (with a minimum of EN149

R2S092) when you are working with this







