



BATTERY (Continued...)

- 6. When the work-contact element is depressed, a continuous green light shows that battery is charged ready for use.
7. A continuous red light shows that the battery is flat and needs recharging.
8. The battery must be removed for recharging. Do not try to improvise.
9. Recharge the battery only with the charger supplied, following the instructions given by the hire company.
10. If you have an rcd, plug it into the 230volt socket. Plug the charger into the rcd.
11. Toxic and flammable fumes are produced when charging some types of batteries. Charging should be carried out in a dry, cool, well-ventilated and safe location.

LOADING NAILS

- 1. Use only nails or other fasteners that have been supplied or specified by the hire company. If different nails are required, contact the hire company.
2. Do not operate the trigger, or have the yoke depressed while loading or unloading.
3. Holding the tool by its handle in your right hand, slide the knob on the left of the magazine back until it locks in position.
4. Insert the strip of fasteners into the slot at the bottom of the magazine.
5. Release the lock by pressing in the button on top of the knob and allowing it to gently push

the strip of fasteners to the firing position. Do not allow the knob to spring back; it might damage the fastener strip.

- 6. As the fasteners are used, the strip will be pushed along. The indicator at the top of the magazine will show when the tool requires reloading.
7. When there are approximately 5 fasteners left a safety mechanism will prevent further operation. Reload a fresh strip of fasteners.
8. Fasteners can be unloaded by following instructions 2 and 3 above. The remaining fasteners will slide out easily.

USING THE CORDLESS NAILER

- 1. Wear protective equipment including goggles and ear defenders.
2. Do not carry a loaded nailer around: unload the fuel cell and battery first.
3. To fix a nail, press the work-contact element against the workpiece, and pull the trigger.
4. This equipment will drive two to three nails per second, or up to 1,000 per hour. Do not try to force it to work faster - it will damage the tool.
5. When working close to the edge of the timber take care not to split it.
6. When finished work, unload and clean the cordless nailer and store it and the fuel cells, battery and fasteners securely.
7. If the equipment is not working properly or appears to be faulty, do not attempt to repair it. Contact the hire company.

Please keep this leaflet safely. It may be required for further information



Hire Association Europe
2450 Regents Court
The Crescent
Birmingham Business Park
Solithull B37 7YE

Telephone: 44 (0) 121 380 4600
Fax: 44 (0) 121 333 4109
Email: mail@hae.org.uk
website: www.hae.org.uk

The rules and procedures in force where people are at work may require the person responsible for this equipment to carry out a specific risk assessment

Read this entire leaflet before using the Paslode IM350

- 1. Plan the use of the paslode so that it can always be used safely.
2. This equipment can be hazardous if misused. It should be used carefully and only by trained operators.
3. The fuel in the cells are highly flammable: any source of ignition including a lighted cigarette, could be hazardous. Take great care not to cause a fire or explosion.
4. Keep non-essential people, especially children, away from the work area. Never allow a child to touch the equipment.
5. Do not insert a fuel cell, battery, or fasteners until required, and remove them when the equipment is not in use.
6. Always keep the nailer pointing away from yourself, and others. Keep your fingers away from the trigger.
7. Do not allow the work-contact element to be accidentally depressed against your body or any other object.
8. Keep the equipment safely in its protective case when it is not in use.
9. Do not indulge in any horseplay or irresponsible behaviour, while using, or working near the cordless nailer.
10. This cordless nailer must not be used by minors, or by anyone under the influence of drugs or alcohol.
11. This equipment is designed for operation by an able bodied adult. Anyone with either temporary or permanent disability must seek expert advice before using it.



Personal Protective Equipment

- 12. The following items of personal protective equipment should be worn: ear muffs or plugs giving protection for levels up to 89 dBA; impact resistant goggles or face shield; strong work gloves.
13. You may also need a residual current device (rcd) if charging batteries form a 230-volt mains supply.



Every effort has been made by HAE/EHA to ensure that the information given in this document and supporting material is accurate and not misleading. HAE/EHA cannot accept responsibility for any loss or liability perceived to have arisen from the use of any such document/material. Only Acts of Parliament and Statutory Instruments have the force of law and only the courts can authoritatively interpret the law.

Any unauthorised reproduction - manually or electronically - is STRICTLY prohibited

Copyright Hire Association Europe April 2011

Telephone: 44 (0) 121 380 4600
Fax: 44 (0) 121 333 4109
Email: mail@hae.org.uk
website: www.hae.org.uk

Hire Association Europe
2450 Regents Court
The Crescent
Birmingham Business Park
Solithull B37 7YE



- 1. The battery will slowly discharge while inserted even if the tool is not being used. Remove the battery if the tool is not being used.
2. Use only the correct batteries for the equipment as supplied or recommended by the hire company.
3. The battery compartment is located on the right side of the magazine. Hold the equipment upside down to insert or remove the battery.
4. The light emitting diode in the handle will display either red or green to indicate the condition of the battery.
5. When the work-contact element is depressed, a continuous green light shows that battery is charged ready for use.

Before Starting Work BATTERY

- 1. The battery will slowly discharge while inserted even if the tool is not being used. Remove the battery if the tool is not being used.
2. Use only the correct batteries for the equipment as supplied or recommended by the hire company.
3. The battery compartment is located on the right side of the magazine. Hold the equipment upside down to insert or remove the battery.
4. The light emitting diode in the handle will display either red or green to indicate the condition of the battery.
5. When the work-contact element is depressed, a continuous green light shows that battery is charged ready for use.

have been supplied or specified by the hire company.

LOADING FUEL CELLS

- 1. Use only fuel cells and metering valves that have been supplied or specified by the hire company.
2. The work-contact element may leave small impressions where it contacts the work surface. If work is required on a finished surface - contact the hire company.
3. Never operate the equipment with the work-contact element removed.
4. Sliding the work-contact element back in towards the machine will increase the depth of penetration, or allow for longer nails.
5. Sliding the bracket away from the machine will decrease the depth of penetration, or allow for shorter nails.
6. When the bracket is in the correct position, replace and tighten the two screws.
7. Reload the fuel cell and battery when you are ready to start using the equipment.
8. Never operate the equipment with the work-contact element removed.
9. The work-contact element may leave small impressions where it contacts the work surface. If work is required on a finished surface - contact the hire company.

DEPTH ADJUSTMENT

- 1. The work-contact element is the part of the tool that is pushed against the work piece. Its position can be adjusted for different depths of penetration and for fasteners of different lengths.
2. The fuel cell and battery must be removed before any adjustment is made.
3. Use the hexagon key (Allen Key) provided to tighten the two screws on the work-contact element.
4. Sliding the work-contact element back in towards the machine will increase the depth of penetration, or allow for longer nails.
5. Sliding the bracket away from the machine will decrease the depth of penetration, or allow for shorter nails.
6. When the bracket is in the correct position, replace and tighten the two screws.
7. Reload the fuel cell and battery when you are ready to start using the equipment.
8. Never operate the equipment with the work-contact element removed.
9. The work-contact element may leave small impressions where it contacts the work surface. If work is required on a finished surface - contact the hire company.



Before Starting Work...

WORK AREA

- 1. Do not use this equipment where there is a fire risk from combustible materials, or flammable liquids and gases.
2. If the tool is to be used for long periods, or in confined spaces ensure there is adequate ventilation to disperse the exhaust fumes.
3. Make sure the work area is clear and safe and that no-one close by or could cause distraction. Only essential people should work in the area when the cordless nailer is being used.
4. This tool should only be used for wood to wood nailing.
5. Using this equipment to drive in ring shank nails that are 3" or longer into pressure treated timber is not recommended.
6. Protect other people from the noise and danger. Warn others to keep away. If possible, put barriers around the work area.
7. Do not use the cordless nailer in the rain or where there is excessive moisture.
8. Impact resistant goggles, or face shield when working with this equipment.
9. Before starting work, make sure you understand how to use the cordless nailer safely with no danger to yourself or others.

OPERATORS

- 1. You should only operate this cordless nailer if you have adequate knowledge and understanding of the equipment and the job to enable you to use it without risk to yourself or others.
2. The following items of personal protective equipment (ppe) are the minimum to that should be worn whenever using the cordless nailer. Particular jobs or environments may require a higher level of protection.
3. This cordless nailer will cause noise levels up to 98 dBA - wear appropriate ear muffs or plugs giving hearing protection for this level as a minimum.
4. Impact resistant goggles, or face shield when working with this equipment.